


CONTENTS



Load Options	Operation	Control	Page
4 x 3A	Impulse	Keypad	1
8 x 2A	Impulse	Keypad	2
8 x 3A	Impulse	Keypad	3
8 x 2A with 8 x matched 1-10V Outputs	Impulse	Keypad	4
4 x 3A with 4 x matched SELV DSI Outputs	Impulse	Keypad	5
4 x 3A & 4 x matched SELV 1-10V Outputs	Impulse	Keypad	6
4 x 3A with 4 x SELV 1-10V with Relay Switching	Impulse	Keypad	7
4 x SELV 1-10V with Relay Switching	Impulse	Keypad	8
8 x SELV 1-10V Outputs	Impulse	Keypad	9
8 x SELV 1-10V with Relay Switching	Impulse	Keypad	10
4 x SELV DSI with 4 x SELV 1-10V Outputs	Impulse	Keypad	11
4 x SELV DSI & 4 x SELV 1-10V with Relay Switching	Impulse	Keypad	12
8 x SELV DSI	Impulse	Keypad	13
4 x 3A	Scene Set	Keypad	14
8 x 2A	Scene Set	Keypad	15
8 x 3A	Scene Set	Keypad	16
8 x 2A with 8 x SELV 1-10v Outputs	Scene Set	Keypad	17
4 x 3A & 4 x SELV DSI Outputs	Scene Set	Keypad	18
4 x 3A & 4 x SELV 1-10v Outputs	Scene Set	Keypad	19
4 x SELV 1-10V with Relay Switching	Scene Set	Keypad	20
4 x 3A with 4 x SELV 1-10V with Relay Switching	Scene Set	Keypad	21
8 x SELV 1-10v Outputs	Scene Set	Keypad	22
8 x SELV 1-10V with Relay Switching	Scene Set	Keypad	23
4 x SELV DSI & 4 x SELV 1-10V Outputs	Scene Set	Keypad	24
4 x SELV DSI with 4 x SELV 1-10V and Relay Switching	Scene Set	Keypad	25
8 x SELV DSI	Scene Set	Keypad	26
4 x 3A	Impulse	Switches	27
8 x 2A	Impulse	Switches	28
8 x 3A	Impulse	Switches	29
8 x 2A with 4 x SELV 1-10v outputs	Impulse	Switches	30
4 x SELV DSI Outputs	Impulse	Switches	31
4 x SELV 1-10v Outputs	Impulse	Switches	32
4 x 1-10v with Relay Switching	Impulse	Switches	33
8 x SELV 1-10v only	Impulse	Switches	34
8 x SELV 1-10v with Relay Switching	Impulse	Switches	35
4 x SELV DSI & 4 x 1-10v outputs only	Impulse	Switches	36
4 x SELV DSI & 4 x 1-10v with Relay Switching	Impulse	Switches	37
8 x SELV DSI	Impulse	Switches	38

Please Note: For full electrical wiring instructions please see installation guides included with each module.



Standalone Function Settings

When used in standalone mode, dimmer modules, relay modules and input / output modules can be set, via the onboard menu, to operate in three different ways:

Scene - Choose this setting if you wish to program and recall multiple channel selections.

Dimming - Choose this setting if you wish to link an individual output channel level to the corresponding channel on an input module.

Impulse - Choose this setting if you wish to control channels 1-8 individually using impulse operation from either a plate button or momentary switch.